

Car MP3 Player



Operation Instructions

1. Set car stereo to an unused FM frequency.
2. To tune MP3 player: Press 'A-' or 'B+' button to increase or decrease frequency.
3. To play or pause: Momentarily press 'play/pause' button.
4. To adjust Volume: Press and hold 'next' or 'previous' button.
5. To change tracks: Momentarily press 'next' or 'previous' button to move forward or back one track at a time.
6. To select repeat modes: Press and hold 'play/pause' button several times to cycle through mode options. ALL (repeat all), ONE (repeat one), rAN (random) or FOf (all in folder).