

# Up Down Timer Instructions



## Features:

- Easy-to-read LCD display.
- 3 buttons on the timer for convenient operation.
- Compact, lightweight & easy to carry.
- Maximum countdown capacity: 99 minutes 59 seconds.
- Loud alarm beep lasting for about 30 seconds when timed out.
- Includes a magnet, clip mounting & stand on the back for easy positioning.

## Operation:

M button: Sets minutes.

S button: Sets seconds.

Start/Stop button: Starts & stops timer.

Count Up Timing:

Press M + S buttons together to zero timer.

Press Start/Stop button to start & stop timer.

Press Start/Stop button again to continue counting if required.

When stopped press M + S buttons together to return to zero.

Count down Timing:

Press 'M' button to set minutes.

Press 'S' button to set seconds.

Press Start/Stop button to start & stop timer.

When the seconds indication reaches Zero the alarm will sound.

Press any button to stop alarm sounding.

Press M + S buttons together to return to zero.

## Specifications:

- Power: 1 x AG13 (LR44) battery (included).
- Diameter: Approx. 64mm diameter x 21mm.

## Notes:

1. This alarm is waterproof in normal operation however should not be immersed in water.
2. If display becomes faint or alarm sound is low, replace battery.